

T-L Basic Controller Features



Monitor	MOUNTED AT THE END TOWER	MOUNTED AT THE PIVOT POINT – REMOTE GPS AT END TOWER
RUNNING	~	~
STOPPED	~	~
PIVOT ANGLE	~	~
TRAVEL DIRECTION	~	~
WATER PRESSURE	~	~
ENDGUN	~	~
ENDGUN MODE	~	~
WET/DRY	~	~
GPS STALL	~	~
INTELLIGENT COLLISION DETECTION	~	~
Control		
START (@ ET IF REPLACING AGSENSE)	~	~
STOP (WITH EXTRA WIRE WHEN END TOWER MOUNT)	✓	~
ENDGUN	✓	~
AUX (WITH EXTRA WIRE WHEN END TOWER MOUNT)	~	~
WATER PUMP CONTROL		✓